


LQ-690C


安裝說明




清點配件




連接電源線



組裝印表機




接續 ➡



將印表機連接至電腦



- 4
- 注意：**
- ❑ 在插入界面連接線之前，請先確認接頭的連接方向是否正確。
 - ❑ 在印表機開機狀態下，請勿插拔連接線。



接續背面 ➡

安裝印表機軟體

5 Windows®



附註：
在 Windows 2000、XP 或 Vista 環境下安裝印表機軟體時，可能必須具有管理員權限。如果您有任何問題，請洽詢管理員。



DOS

① DLQ-3250K	⑩ LQ-1070/1070+
② DLQ-3000K/3000K+	⑪ DLQ-2000
③ LQ-2080	⑫ LQ-1060
④ LQ-2180	⑬ LQ-1050
⑤ LQ-2070	⑭ LQ-2550
⑥ LQ-2170	⑮ LQ-2500
⑦ LQ-1170	


透過您的 DOS 應用軟體的安裝過程或是設定功能，在適當的步驟中選擇您所使用的印表機機型，或其他相容的印表機機型。請依照清單中的先後順序，挑選相容的印表機驅動程式。

放置紙張

6 使用推送式牽引器列印連續報表紙



列印單張紙



7 印表機安裝完成，並準備就緒

關於印表機和故障排除的詳細資訊，請雙擊電腦桌面上的“LQ-690C 進階使用說明”圖示。



EPSON
LQ-690C 進
階使用說明

其他資訊

- 電力規格**
- 額定電壓：110V ± 10%
 - 額定電壓：50 - 60 ± 3%
 - 額定電流：11A
 - 耗電量：37 W (ISO/IEC 10561 letter pattern)

- 警語**
- 檢修本產品之前，請先拔掉本產品的電源線。
- 功能規格**
- 列印方式：撞擊式點矩陣
 - 適用系統：Microsoft Windows Vista、Windows XP、2000

- 緊急處理方法**
- 發生下列狀況時，請先拔下印表機的電源線並洽詢 Epson 授權服務中心：
- 電源線或插頭損壞
 - 有液體噴灑到印表機
 - 印表機摔落或鐵架損壞
 - 印表機無法正常操作或是列印品質與原來有明顯落差

注意事項

- 只能使用印表機標籤上所註明的電源規格。
- 請遵守印表機上所有的警示和說明。

製造年份及製造號碼：見機體標示
生產國別：見機體標示

製造廠商：SEIKO EPSON CORPORATION
地址：80 Harashinden, Hirooka, Shiojiri-shi, Nagano-Ken, 399-0785, JAPAN
電話：81-263-52-2552

進口商：台灣愛普生科技股份有限公司
地址：台北市信義區松仁路 7 號 14 樓
電話：(02) 8786-6688 (代表號)
電話：81-263-52-2552

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to use of the information contained herein. Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions. Seiko Epson Corporation and its affiliates shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation. EPSON is a registered trademark of Seiko Epson Corporation. Microsoft, Windows, and Windows Vista are registered trademarks of Microsoft Corporation in the United States and/or other countries.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

Copyright © 2008 Seiko Epson Corporation. All rights reserved.
Printed in XXXXXX XX.XX-XX XXX