Epson Perfection™ V33 / V330 Photo

安裝說明

411850100

Printed in XXXXXX

ENERGY STAR

1. 清點配件

Perfection V33



電源線

USB 連接線

軟體光碟片

Perfection V330 Photo



電源線

USB 連接線

軟體光碟片



底片固定夾

2. 安裝軟體



警告：
請勿連接電腦與掃描器間的 USB 連接線。

放入軟體光碟片

Mac OS X 使用者

Windows 使用者

選擇語言，然後按下『簡易安裝』

點選〝接受〞，然後按下『下一步』

依螢幕上的指示操作

安裝完成，請按下『完成』

3. 掃描



將原稿的正面朝下放在工作平台上



輕輕闔上掃描器上蓋以免照片產生位移



按下『⟐』鍵

按下『**掃描**』鍵



Epson Scan 會以〝**全自動模式**〞進行掃描，直到掃描完成。

取得更多的資訊

請雙擊桌面上〝Epson Perfection V33/V330 Photo 進階使用說明〞圖示開啓進階使用說明，即可瀏覽有關產品的操作、日常維護、解決問題的方法和技術規格等說明。

其他資訊

電力規格
- 額定電壓：DC 13.5 V
- 額定輸入電流：1.2 A
- 耗電量：操作時約 12.0 W

功能規格

適用系統：Microsoft Windows 7, Vista, XP Home Edition, XP Professional Edition, XP Professional x64 Edition, Mac OS X 10.3..9 或以上版本

警語

檢修本產品之前，請先拔掉本產品的電源線。

注意事項
- 選擇電源時，只可使用標示在掃描器背面標籤上的電源規格。
- 請遵守掃描器上所有的警示和說明

緊急處理方法

發生下列狀況時，請先拔下印表機的電源線並洽詢 Epson 授權服務中心：
- 電源線或插頭損壞
- 有液體噴灑到掃描器
- 掃描器摔落
- 掃描器無法正常操作或所呈現的掃描效果與預期的結果有明顯落差

使用方法：見內附相關說明文件。

製造年份及製造號碼：見機體標示
生產國別：見機體標示

製造商：SEIKO EPSON CORPORATION
地址：80 Harashinden, Hirooka, Shiojiri-shi, Nagano-Ken, 399-0785, JAPAN
電話：81-263-52-2552

進口商：台灣愛普生科技股份有限公司
地址：台北市信義區松仁路 7 號 14 樓
電話：(02) 8786-6688 (代表號)

EPSON
EXCEED YOUR VISION

EPSON® is a registered trademark, and EPSON Perfection™ and EPSON EXCEED YOUR VISION or EXCEED YOUR VISION are trademarks of Seiko Epson Corporation.
General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners.
Epson disclaims any and all rights in those marks. © 2010 Seiko Epson Corporation. All rights reserved.